



This drawing, specifications, and concepts contained herein are the sole property of Red Barn Machine, and may not be reproduced or used in any fashion without the prior written permission of Red Barn Machine.

 THREAD -1 ADAPTER ON TO -5 ROD
TO 2 TURNS. HOLD WITH -1 SMALL ROUND PART POINTING DOWN.

4. ROLL THE BLADE ASSEMBLY 180°. USING THE -9 SPUD, PLACE IT THROUGH THE BOTTOM BUSHING HOLE AS SHOWN AND INTO THE TOP BUSHING.

5. USING A SMALL HAMMER TAP THE TOP BUSHING FREE OF THE GRIP

ASSEMBLY INTO THE -11 BUSHING RECEIVER.

2. PLACE ADAPTER ASSEMBLY INTO THE GRIP WITH THE -1 SOLID ROUND IN THE BOTTOM BUSHING CENTER. PLACE THE -3 SPUD THROUGH THE TOP BUSHING AND INTO THE -1 ADAPTER FIRMLY AS SHOWN. WHILE HOLDING THE ADAPTER FIRMLY, UNTHREAD -5 ROD AND REMOVE.

3. WHILE HOLDING -1 ADAPTER FIRMLY WITH -3 SPUD, USE A SMALL HAMMER AND TAP THE BOTTOM BUSHING FREE FROM THE GRIP ASSEMBLY INTO THE -11 BUSHING RECEIVER.

RED BARN MACHINE 190 S. DANEBO AVE. Eugene, Oregon 97402

(541) 344-9953; fax (541) 344-3863 e-mail; sales@redbarn.net @ RED BARN MACHINE

TAIL ROTOR BLADE BUSHING REMOVAL TOOL INSTRUCTIONS

RBT18635

1 of 1



